



## **Easy read high concentrations chlorine test strips sanitizer**

### **Description**

- **Product Description**
- **High concentration chlorine test strips 2000 mg/L test kit chlorine sanitizer equipment.**
- **Parameter:**
- **Shelf life:**
- **two years. Better use up within 90 days after opening.**

- **Fast Results & Easy Read:**
- **1.Remove one strip from the bottle and screw the cap immediately and tightly.**
- **2.Immerse the reagent area of the strip in the water specimen 2 seconds and take it out quickly.Don't shake off excess water on the strip.**
- **3.Read the test results carefully within 90 seconds in a natural light and with the test area held near the appropriate color chart on the bottle label.**
- **WARNINGS**
- **1.The desiccant should keep in bottle for the aim of preserving the reaction activity of reagent.**
- **2.Do not touch test pads of strip with wet fingers.**
- **3.Store the strips in a cool,dry place to help them maintain a long shelf life.Do not open bottle until ready to use.**